

Appendix III-B

Western Washington Hydrology Model – Information, Assumptions, and Computation Steps

The information and assumptions used in the Western Washington Hydrology Model (WWHM) are described in this document.

WWHM Limitations

The WWHM has been created for the specific purpose of sizing stormwater control facilities for new development and redevelopment projects in Western Washington. The WWHM can be used for a range of conditions and developments; however, certain limitations are inherent in this software. These limitations are described below.

The WWHM uses the EPA HSPF software program to do all of the rainfall-runoff and routing computations. Therefore, HSPF limitations are included in the WWHM. For example, backwater or tailwater control situations are not explicitly modeled by HSPF. This is also true in the WWHM.

In addition, the WWHM is limited in its routing capabilities. The user is allowed to input a single stormwater control facility and runoff is routed through this facility. If the proposed development site contains multiple facilities in series or involves routing through a natural lake, pond, or wetland in addition to a stormwater control facility then the user should use HSPF to do the routing computations and additional analysis.

Routing effects become more important as the drainage area increases. For this reason it is recommended that the WWHM not be used for drainage areas greater than one-half square mile (320 acres). The WWHM can be used for small drainage areas down to less than an acre in size.

WWHM Information and Assumptions

1. Precipitation data.

Length of record.

The WWHM uses long-term (43-50 years) precipitation data to simulate the potential impacts of land use development in western Washington. A minimum period of 20 years is required to simulate enough peak flow events to produce accurate flow frequency results. A 40 to 50-year record is preferred. The actual length of record of each precipitation station varies, but all exceed 43 years.

Rainfall distribution.

The precipitation data are representative of the different rainfall regimes found in western Washington. A total of 17 precipitation stations are used. These stations represent rainfall at elevations below 1500 feet. Snowfall and melt are not included in the WWHM.

The primary source for precipitation data is National Weather Service stations. The secondary source is precipitation data collected by local jurisdictions. During development of WWHM, county engineers at 19 western Washington counties were contacted to obtain local precipitation data. Only King County provided local data.

The following precipitation stations have been included in the WWHM:

Precipitation Station	Years of Data	County Coverage
Astoria, OR	1955-1998 = 43	Wahkiakum
Blaine	1948-1998 = 50	Whatcom, San Juan
Burlington	1948-1998 = 50	Skagit, Island
Clearwater	1948-1998 = 50	Jefferson (west)
Darrington	1948-1996 = 48	Snohomish (northeast)
Everett	1948-1996 = 48	Snohomish (excluding northeast)
Frances	1948-1998 = 50	Pacific
Landsburg	1948-1997 = 49	King (east)
Longview	1955-1998 = 43	Cowlitz, Lewis (south)
McMillian	1948-1998 = 50	Pierce
Montesano	1955-1998 = 43	Grays Harbor
Olympia	1955-1998 = 43	Thurston, Mason (south), Lewis (north)
Port Angeles	1948-1998 = 50	Clallam (east)
Portland, OR	1948-1998 = 50	Clark, Skamania
Quilcene	1948-1998 = 50	Jefferson (west east), Mason (north), Kitsap
Sappho	1948-1998 = 50	Clallam (west)
SeaTac	1948-1997 = 49	King (west)

The records were reviewed for length, quality, and completeness of record. Annual totals were checked along with hourly maximum totals. Using these checks, data gaps and errors were corrected, where possible. A "Quality of Record" summary was produced for each precipitation record reviewed.

The reviewed and corrected data were placed in multiple WDM (Watershed Data Management) files. One WDM file was created per county and contains all of the precipitation data to be used by the WWHM for that particular county.

Computational time step.

The computational time step used in the WWHM is one hour. The one-hour time step was selected to better represent the temporal variability of actual precipitation than daily data.

2. Precipitation multiplication factors.

Precipitation multiplication factors increase or decrease recorded precipitation data to better represent local rainfall conditions. This is particularly important when the precipitation gage is located some distance from the study area.

Precipitation multiplication factors were developed for western Washington. The factors are based on the ratio of the 24-hour, 25-year rainfall intensities for the representative precipitation gage and the surrounding area represented by that gage's record. The 24-hour, 25-year rainfall intensities were determined from the NOAA Atlas 2 (*Precipitation-Frequency Atlas of the Western United States, Volume IX – Washington, 1973*).

These multiplication factors were created for the Puget Sound lowlands plus all western Washington valleys and hillside slopes below 1500 feet elevation. The factors were placed in the WWHM database and linked to each county's map. They are transparent to the general user. The advanced user will have the ability to change the precipitation multiplication factor for a specific site. However, such changes will be recorded in the WWHM output.

3. Pan evaporation data.

Pan evaporation data are used to determine the potential evapotranspiration (PET) of a study area. Actual evapotranspiration (AET) is computed by the WWHM based on PET and available moisture supply. AET accounts for the precipitation that returns to the atmosphere without becoming runoff. Soil moisture conditions and runoff are directly influenced by PET and AET.

Evaporation is not highly variable like rainfall. Puyallup pan evaporation data are used for all of the 19 western Washington counties.

Pan evaporation data were assembled and checked for the same time period as the precipitation data and placed in the appropriate county WDM files.

Pan evaporation data are collected in the field, but PET is used by the WWHM. PET is equal to pan evaporation times a pan evaporation coefficient. Depending on climate, pan evaporation coefficients for western Washington range from 0.72 to 0.82.

NOAA Technical Report NWS 33, *Evaporation Atlas for the Contiguous 48 United States*, was used as the source for the pan evaporation coefficients. Pan evaporation coefficient values are shown on Map 4 of that publication.

As with the precipitation multiplication factors, the pan evaporation coefficients have been placed in the WWHM database and linked to each county's map. They will be transparent to the general user. The advanced user will have the ability to change the coefficient for a specific site. However, such changes will be recorded in the WWHM output.

4. Soil data.

Soil type, along with vegetation type, greatly influences the rate and timing of the transformation of rainfall to runoff. Sandy soils with high infiltration rates produce little or no surface runoff;

almost all runoff is from groundwater. Soils with a compressed till layer slowly infiltrate water and produce larger amounts of surface runoff during storm events.

The WWHM uses three predominate soil type to represent the soils of western Washington: till, outwash, and saturated

Till soils have been compacted by glacial action. Under a layer of newly formed soil lies a compressed soil layer commonly called "hardpan". This hardpan has very poor infiltration capacity. As a result, till soils produce a relatively large amount of surface runoff and interflow. A typical example of a till soil is an Alderwood soil (SCS class C).

Outwash soils have a high infiltration capacity due to their sand and gravel composition. Outwash soils have little or no surface runoff or interflow. Instead, almost of their runoff is in the form of groundwater. An Everett soil (SCS class A) is a typical outwash soil.

Outwash soils over high groundwater or an impervious soil layer have low infiltration rates and act like till soils. Where groundwater or an impervious soil layer is within 5 feet from the surface, outwash soils may be modeled as till soils in the WWHM.

Saturated soils are usually found in wetlands. They have a low infiltration rate and a high groundwater table. When dry, saturated soils have a high storage capacity and produce very little runoff. However, once they become saturated they produce surface runoff, interflow, and groundwater in large quantities. Mukilteo muck (SCS class D) is a typical saturated soil.

The user will be required to investigate actual local soil conditions for the specific development planned. The user will then input the number of acres of outwash (A/B), till (C), and saturated (D) soils for the site conditions.

Alluvial soils are found in valley bottoms. These are generally fine-grained and often have a high seasonal water table. There has been relatively little experience in calibrating the HSPF model to runoff from these soils, so in the absence of better information, these soils may be modeled as till soils.

Additional soils will be included in the WWHM if appropriate HSPF parameter values are found to represent other major soil groups.

The three predominate soil types are represented in the WWHM by specific HSPF parameter values that represent the hydrologic characteristics of these soils. More information on these parameter values is presented below.

5. Vegetation data.

As with soil type, vegetation types greatly influence the rate and timing of the transformation of rainfall to runoff. Vegetation intercepts precipitation, increases its ability to percolate through the soil, and evaporates and transpires large volumes of water that would otherwise become runoff.

The WWHM will represent the vegetation of western Washington with three predominate vegetation categories: forest, pasture, and lawn (also known as grass).

Forest vegetation represents the typical second growth Douglas fir found in the Puget Sound lowlands. Forest has a large interception storage capacity. This means that a large amount of precipitation is caught in the forest canopy before reaching the ground and becoming available for runoff. Precipitation intercepted in this way is later evaporated back into the atmosphere. Forest also has the ability to transpire moisture from the soil via its root system. This leaves less water available for runoff.

Pasture vegetation is typically found in rural areas where the forest has been cleared and replaced with shrub or grass lots. Some pasture areas may be used to graze livestock. The interception storage and soil evapotranspiration capacity of pasture are less than forest. Soils may have also been compressed by mechanized equipment during clearing activities. Livestock can also compact soil. Pasture areas typically produce more runoff (particularly surface runoff and interflow) than forest areas.

Lawn vegetation is representative of the suburban vegetation found in typical residential developments. Soils have been compacted by earth moving equipment, often with a layer of topsoil removed. Sod and ornamental bushes replace native vegetation. The interception storage and evapotranspiration of lawn vegetation is less than pasture. More runoff results.

Predevelopment default land conditions are forest, although the user has the option of specifying pasture if there is documented evidence that pasture vegetation was native to the predevelopment site. If this option is used, the change will be recorded in the WWHM output.

Forest vegetation is represented by specific HSPF parameter values that represent the forest hydrologic characteristics. As described above, the existing regional HSPF parameter values for forest are based on undisturbed second-growth Douglas fir forest found today in western Washington lowland watersheds.

Postdevelopment vegetation will reflect the new vegetation planned for the site. The user has the choice of forest, pasture, and landscaped vegetation. Forest and pasture are only appropriate for postdevelopment vegetation in parcels separate from standard residential or non-standard residential/commercial. Development areas must only be designated as forest or pasture where legal restrictions can be documented that protect these areas from future disturbances. The WWHM assumes the pervious land portion of ~~developed areas the standard residential and non-standard residential/commercial~~ is covered with lawn vegetation, as described above.

6. Development land use data.

The WWHM user must enter land use information for the pre-developed condition and the proposed development condition into the model.

There are 6 basic land use categories and 3 soil types available in the WWHM2. The land use categories are: Impervious Area (Roof), Streets/Sidewalks/Parking, Landscaped Area (this is

modeled as includes lawn, garden, areas with ornamental plants, and any natural areas not legally protected from future disturbance)), Forest, Pasture, and Pond. The soils types are A/B (outwash), C/D (Till), and Saturated (wetland).

Forest and pasture vegetation areas are only appropriate for separate undeveloped parcels dedicated as open space, wetland buffer, or park within the total area of the standard residential development. *Development areas must only be designated as forest or pasture where legal restrictions can be documented that protect these areas from future disturbances.*

Impervious, as the name implies, allows no infiltration of water into the pervious soil. All runoff is surface runoff. Impervious land typically consists of paved roads, sidewalks, driveways, and parking lots. Roofs are also impervious.

For the purposes of hydrologic modeling, only effective impervious area is categorized as impervious. Effective impervious area (EIA) is the area where there is no opportunity for surface runoff from an impervious site to infiltrate into the soil before it reaches a conveyance system (pipe, ditch, stream, etc.). An example of an EIA is a shopping center parking lot where the water runs off the pavement and directly goes into a catch basin where it then flows into a pipe and eventually to a stream. In contrast, some homes with impervious roofs collect the roof runoff into roof gutters and send the water down downspouts. When the water reaches the base of the downspout it can be directed either into a pipe (which is connected to the local storm sewer), dumped onto a splash block, or directed into a dispersion trench. Roof water sent to a dispersion trench has the opportunity to spread out into the yard and soak into the soil. Such roofs are not considered to be effective impervious area if the criteria in Section 3.1.2. are met (see below for more information).

The non-effective impervious area uses the adjacent or underlying soil and vegetation properties. Vegetation often varies by the type of land use. The assumption is made in the WWHM that the EIA equals the TIA (total impervious area). This is consistent with King County's determination of EIA acres for new developments. Where appropriate, the TIA can be reduced through the use of runoff credits (more on that below).

In addition, WWHM2 offers the following 2 optional features:

Standard Residential: For housing developments where lot-specific details (e.g., size of roof and driveway) information on what goes on each lot are not yet determined, is lacking, the WWHM provides a set of default assumptions. ~~Standard residential development makes specific assumptions~~ about the amount of impervious area per lot and its division between driveways and rooftops. ~~Streets and sidewalk areas are input separately.~~ Ecology has selected a standard impervious area of 4200 square feet per residential lot, with 1000 square feet of that as driveway, walkways, and patio area, and the remainder as rooftop area. The rest of the lot acres will be assumed to be landscaped area (including lawngrass). The user inputs the number of residential lots and the total acreage of the residential lots (public right-of-way acreages and non-residential lot acreages excluded). The number of residential lots and the associated number of acres will be used to compute the average number of residential lots per acre. This value together with the number of residential lots and the impervious area in the public right-of-way will be used by the

model to calculate the TIA for the proposed development. The areas covered by streets, parking areas, and sidewalk areas are input separately by the user.

Runoff Credits: Used to model dispersal or infiltration of roof runoff, and apply credit for the use of porous pavement.

Development land use data are used to represent the type of development planned for the site and are used to determine the appropriate size of the required stormwater mitigation facility.

~~For the purposes of the WWHM in western Washington developed land is divided into two major categories:~~

- ~~1. standard residential, and~~
- ~~2. non-standard residential/commercial.~~

Standard residential

~~Standard residential development makes specific assumptions about the amount of impervious area per lot and its division between driveways and rooftops. Streets and sidewalk areas are input separately. Ecology has selected a standard impervious area of 4200 square feet per residential lot, with 1000 square feet of that as driveway, walkways, and patio area, and the remainder as rooftop area.~~

~~Impervious, as the name implies, allows no infiltration of water into the pervious soil. All runoff is surface runoff. Impervious land typically consists of paved roads, sidewalks, driveways, and parking lots. Roofs are also impervious.~~

~~For the purposes of hydrologic modeling, only effective impervious area is categorized as impervious. Effective impervious area (EIA) is the area where there is no opportunity for surface runoff from an impervious site to infiltrate into the soil before it reaches a conveyance system (pipe, ditch, stream, etc.). An example of an EIA is a shopping center parking lot where the water runs off the pavement and directly goes into a catch basin where it then flows into a pipe and eventually to a stream. In contrast, some homes with impervious roofs collect the roof runoff into roof gutters and send the water down downspouts. When the water reaches the base of the downspout it can be directed either into a pipe or dumped on a splash block. Roof water dumped on a splash block then has the opportunity to spread out into the yard and soak into the soil. Such roofs are not considered to be effective impervious area. For hydrologic modeling purposes, runoff credits are given to developments that contain houses that have roof runoff systems that disperse roof runoff and allow it to drain into the soil. A runoff credit is given by assuming in the modeling that the roof area behaves hydrologically as lawn rather than EIA.~~

~~The non-effective impervious area uses the adjacent or underlying soil and vegetation properties. Vegetation often varies by the type of land use. Standard residential and non-standard residential/commercial are both assumed to have lawn as their typical pervious area vegetation.~~

~~The assumption is made in the WWHM that the EIA equals the TIA (total impervious area). This is consistent with King County's determination of EIA acres for new developments. Where appropriate, the TIA can be reduced through the use of runoff credits (more on that below).~~

~~For standard residential developments the user will input the impervious area in the public right-of-way (streets and sidewalks). In addition, the user will input the number of residential lots and the number of acres associated directly with these residential lots (public right-of-way acreages and non-residential lot acreages excluded). The number of residential lots and the associated number of acres will be used to compute the average number of residential lots per acre. This value together with the number of residential lots and the impervious area in the public right-of-way will be used by the model to calculate the TIA for the proposed development.~~

~~Runoff credits will be given reducing runoff from standard residential lots/developments.~~
Runoff credits can be obtained using any or all of the low impact development ~~three methods~~ listed below. The WWHM2 has an automated procedure for taking credits for infiltrating or dispersing roof runoff - methods #1 and #2 below. ~~credits for described below.~~ Credits for using methods 4, 6, 7, and 8 must be taken by following the guidance in Appendix C. Roof areas using method #5 -rainwater harvesting systems- designed in accordance with the guidance in Appendix C need not be entered into the model. Also, if using method 9 – Full dispersion – the runoff model need not be used for the area that meets the criteria in Appendix C.

1. Infiltrate roof runoff
2. Disperse roof runoff
3. ~~Use p~~Porous pavement for driveways and walks-areas
4. Vegetated Roofs
5. Rainwater Harvesting
6. Reverse slope sidewalks
7. Low impact foundations
8. Rain Gardens (Bioretention Areas)
9. Full dispersion

1. Infiltrate Roof Runoff

Credit is given for disconnecting the roof runoff from the development's stormwater conveyance system and infiltrating on the individual residential lots. The WWHM assumes that this infiltrated roof runoff does not contribute to the runoff flowing to the stormwater detention pond site. It disappears from the system and does not have to be mitigated. See Section 3.1.1. of Volume III for design requirements for downspout infiltration systems.

2. Disperse Roof Runoff

Credit is also given for disconnecting the roof runoff from the development's stormwater conveyance system and dispersing it on the surface of individual lots. If the runoff is dispersed using a dispersion trench designed according to the requirements of Section 3.1.2. of Volume III, on single-family lots greater than 22,000 square feet, and the vegetative flow path of the runoff is 50 feet or longer through undisturbed native or compost-amended soils, the roof area can be entered into the model as landscaped area rather than impervious surface. This runoff is assumed to be the equivalent of runoff from lawn vegetation.

3. Porous pavement for driveways and walks

The third option for runoff credit is the use of porous pavement for private driveways, sidewalks, streets, and parking areas. The WWHM2 currently includes an option for obtaining credits for the use of porous pavements on Streets/Sidewalk/Parking. The credit given under this option is believed to be too small. a button to push if porous pavements are used on a driveway. That button should no longer be used. Until such time as WWHM2 is upgraded to WWHM3, the LID credit guidance in Appendix C should be followed. It will direct you to enter a certain percentage of the pervious pavement area into the ~~lawn~~ landscaped area category rather than the street/sidewalk/parking lot category.

Similar procedures should be followed for vegetated roofs, reverse slope sidewalks, and low impact foundations. The LID credit guidance of Appendix C directs how these surfaces should be entered into the model. ~~the “Non-standard residential/commercial” input screen should be used whenever a project incorporates porous pavements on residential lots. Specific HSPF parameters for porous pavement have not been developed for the WWHM. Ecology has made the assumption that porous pavement runoff is the equivalent to the conversion of 147 square feet (1000*0.147) of impervious area to lawn vegetation. This assumption is used in the WWHM calculations. If you do not know the specific quantities of the different land cover types for your development (e.g., the individual lots will be sold to builders who will determine layout and size of home), you should start with the assumption of 4200 sq. ft. of impervious area per lot – including 1,000 sq. ft. for driveways, and begin making adjustments in those totals as allowed in the LID guidance of Appendix C.~~

~~Forest and pasture vegetation areas are only appropriate for separate undeveloped parcels dedicated as open space, wetland buffer, or park within the total area of the standard residential development. Development areas must only be designated as forest or pasture where legal restrictions can be documented that protect these areas from future disturbances.~~

Non-standard residential/commercial

Non-standard residential/commercial development includes residential developments for which the standard residential developments assumptions are inappropriate, plus commercial, industrial, schools, roads, multi-family residential (apartments, condos), and other non-single family residential developments. For this type of development the user will input the roof area, landscape area, street/sidewalk/parking areas, and any appropriate non-developed forest and pasture areas. Developed runoff will be calculated based on these categories and their areas.

The only explicit runoff credit available to the user is porous pavement for streets, sidewalks, and parking lots. The credit works the same way as for standard residential. It is specified as 14.7% of the total street/sidewalk/parking impervious area. The user can also implicitly obtain other runoff credits for roof infiltration by decreasing or eliminating roof area where roof runoff is infiltrated. Roof runoff that is dispersed as described in method #2 above, can be or by modeling by inputting the roof area as lawn/landscape area, where roof runoff is dispersed in accordance with the infiltration and dispersion requirements in Chapter 3. This will decrease surface runoff.

WWHM2 includes a button for indicating what part of the streets, sidewalks, and parking lots will be placed in porous pavement. This button should not be used at this time. Instead, the LID credit guidance in Appendix C should be followed. It will direct you to enter a certain percentage of the pervious pavement area into the lawn/landscape category rather than the street/sidewalk/parking lot category. Similar procedures should be followed for vegetated roofs, reverse slope sidewalks, and low impact foundations. The LID credit guidance of Appendix C directs how these surfaces should be entered into the model.

Roof areas using rainwater harvesting systems designed in accordance with the guidance in Appendix C need not be entered into the model. Sites meeting the criteria for full

~~dispersion need not use the runoff model at all. Finally, more detailed procedures are included in Appendix C for modeling rain gardens (bioretention areas).~~

~~Forest and pasture vegetation areas are only appropriate for separate undeveloped parcels dedicated as open space, wetland buffer, or park within the total area of the development. Development areas must only be designated as forest or pasture where legal restrictions can be documented that protect these areas from future disturbances.~~

Other Development Options and Model Features

The WWHM allows the flexibility of bypassing a portion of the development area around a flow control facility and/or having offsite inflow that is entering the development area pass through the flow control facility. ~~Three options are available to the user:~~

~~A. Design Basin: usual development situation with no offsite inflow and no flow bypass.~~

~~B. Bypass occurs when:~~ a portion of the development does not drain to a stormwater detention facility. Onsite runoff from a proposed development project may bypass the flow control facility provided that all of the following conditions are met.

1. Runoff from both the bypass area and the flow control facility converges within a quarter-mile downstream of the project site discharge point, and
2. The flow control facility is designed to compensate for the uncontrolled bypass area such that the net effect at the point of convergence downstream is the same with or without bypass, and
3. The 100-year peak discharge from the bypass area will not exceed 0.4 cfs, and
4. Runoff from the bypass area will not create a significant adverse impact to downstream drainage systems or properties, and
5. Water quality requirements applicable to the bypass area are met.

~~C. Offsite Inflow occurs when:~~ an upslope area outside the development drains to the flow control facility in the development. If the existing 100-year peak flow rate from any upstream offsite area is greater than 50% of the 100-year developed peak flow rate (undetained) for the project site, then the runoff from the offsite area must not flow to the onsite flow control facility. The bypass of offsite runoff must be designed so as to achieve the following:

1. Any existing contribution of flows to an onsite wetland must be maintained, and
2. Offsite flows that are naturally attenuated by the project site under predeveloped conditions must remain attenuated, either by natural means or by providing additional onsite detention so that peak flows do not increase.

~~For each of these options the user inputs the number of acres in the different categories for the predevelopment and postdevelopment land use. The WWHM computes the runoff from each separately and adds them together, as appropriate, to check to see if the stormwater standards have been satisfied. The following~~

~~WWHM uses this information to compute the corresponding number of acres of pervious and impervious land and assign these acres to specific PERLNDs and IMPLNDs. These terms are~~

~~HSPF speak for pervious land categories and impervious land categories. WWHM uses the PERLNDs and IMPLNDs to compute postdevelopment runoff.~~

Application of WWHM in Re-developments Projects

WWHM allows only forest or pasture as the predevelopment land condition in the Design Basin screen. This screen does not allow other types of land uses such as impervious and landscaped areas to be entered for existing condition. However, WWHM can be used for redevelopment projects by modeling the existing developed areas that are not subject to the flow control requirements of Volume I as offsite areas. For the purposes of predicting runoff from such an existing developed area, enter the existing area in the Offsite Inflow screen. This screen is designed to predict runoff from impervious and landscaped areas in addition to the forest and pasture areas. If the existing 100-year peak flow rate from the existing developed areas that are not subject to flow control is greater than 50% of the 100-year developed peak flow rate (undetained but subject to the flow control requirements of Volume I), then the runoff from the offsite area must not be allowed to flow to the onsite flow control facility.

7. PERLND and IMPLND parameter values.

In WWHM (and HSPF) pervious land categories are represented by PERLNDs; impervious land categories (EIA) by IMPLNDs. An example of a PERLND is a till soil covered with forest vegetation. This PERLND has a unique set of HSPF parameter values. For each PERLND there are 16 parameters that describe various hydrologic factors that influence runoff. These range from interception storage to infiltration to active groundwater evapotranspiration. Only four parameters are required to represent IMPLND.

The PERLND and IMPLND parameter values to be used in the WWHM are listed below. These values are based on regional parameter values developed by the U.S. Geological Survey for watersheds in western Washington (Dinicola, 1990) plus additional HSPF modeling work conducted by AQUA TERRA Consultants.

PERLND Parameters

	TF	TP	TL	OF	OP	OL	SF	SP	SL
Name									
LZSN	4.5	4.5	4.5	5.0	5.0	5.0	4.0	4.0	4.0
INFILT	0.08	0.06	0.03	2.0	1.6	0.80	2.0	1.8	1.0
LSUR	400	400	400	400	400	400	100	100	100
SLSUR	0.10	0.10	0.10	0.10	0.10	0.10	0.001	0.001	0.001
KVARY	0.5	0.5	0.5	0.3	0.3	0.3	0.5	0.5	0.5
AGWRC	0.996	0.996	0.996	0.996	0.996	0.996	0.996	0.996	0.996
INFEXP	2.0	2.0	2.0	2.0	2.0	2.0	10.0	10.0	10.0
INFILD	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0
BASETP	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
AGWETP	0.0	0.0	0.0	0.0	0.0	0.0	0.7	0.7	0.7
CEPSC	0.20	0.15	0.10	0.20	0.15	0.10	0.18	0.15	0.10
UZSN	0.5	0.4	0.25	0.5	0.5	0.5	3.0	3.0	3.0
NSUR	0.35	0.30	0.25	0.35	0.30	0.25	0.50	0.50	0.50

INTFW	6.0	6.0	6.0	0.0	0.0	0.0	1.0	1.0	1.0
IRC	0.5	0.5	0.5	0.7	0.7	0.7	0.7	0.7	0.7
LZETP	0.7	0.4	0.25	0.7	0.4	0.25	0.8	0.8	0.8

PERLND types:

TF = Till Forest

TP = Till Pasture

TL = Till Lawn

OF = Outwash Forest

OP = Outwash Pasture

OL = Outwash Lawn

SF = Saturated Forest

SP = Saturated Pasture

SL = Saturated Lawn

PERLND parameters:

LZSN = lower zone storage nominal (inches)

INFILT = infiltration capacity (inches/hour)

LSUR = length of surface overland flow plane (feet)

SLSUR = slope of surface overland flow plane (feet/feet)

KVARY = groundwater exponent variable (inch^{-1})

AGWRC = active groundwater recession constant (day^{-1})

INFEXP = infiltration exponent

INFILD = ratio of maximum to mean infiltration

BASETP = base flow evapotranspiration (fraction)

AGWETP = active groundwater evapotranspiration (fraction)

CEPSC = interception storage (inches)

UZSN = upper zone storage nominal (inches)

NSUR = roughness of surface overland flow plane (Manning's n)

INTFW = interflow index

IRC = interflow recession constant (day^{-1})

LZETP = lower zone evapotranspiration (fraction)

A more complete description of these PERLND parameters is found in the HSPF User Manual (Bicknell et al, 1997).

PERLND parameter values for other additional soil/vegetation categories will be investigated and added to the WWHM, as appropriate.

IMPLND Parameters

	EIA
Name	
LSUR	400
SLSUR	0.01
NSUR	0.10
RETSC	0.10

IMPLND parameters:

LSUR = length of surface overland flow plane (feet)

SLSUR = slope of surface overland flow plane (feet/feet)

NSUR = roughness of surface overland flow plane (Manning's n)
RETSC = retention storage (inches)

A more complete description of these IMPLND parameters is found in the HSPF User Manual (Bicknell et al, 1997).

The PERLND and IMPLND parameter values will be transparent to the general user. The advanced user will have the ability to change the value of a particular parameter for that specific site. However, such changes will be recorded in the WWHM output.

Surface runoff and interflow will be computed based on the PERLND and IMPLND parameter values. Where groundwater flow from small catchments reaches the surface and becomes runoff, the Ggroundwater flow ~~will not~~ can be computed and added to give the total runoff (i.e., surface runoff, interflow, and groundwater. ,as it is assumed that there is no groundwater flow from small catchments that reaches the surface to become runoff. This is consistent with King County procedures (King County, 1998).

8. Guidance for flow control standards.

Flow control standards are used to determine whether or not a proposed stormwater facility will provide a sufficient level of mitigation for the additional runoff from land development. Guidance is provided on the standards that must be met to comply with the Ecology Stormwater Management Manual.

There are two flow control standards stated in the Ecology Manual: Minimum Requirement #7 - Flow Control and Minimum Requirement #8 - Wetlands Protection (See Volume I). Minimum Requirement #7 specifies flow frequency and flow duration ranges for which the postdevelopment runoff cannot exceed predevelopment runoff. Minimum Requirement #8 specifies that discharges to wetlands must maintain the hydrologic conditions, hydrophytic vegetation, and substrate characteristics necessary to support existing and designated beneficial uses.

Minimum Requirement #7 specifies that stormwater discharges to streams shall match developed discharge durations to predeveloped durations for the range of predeveloped discharge rates from 50% of the 2-year peak flow up to the full 50-year peak flow. ~~In addition, the developed peak discharge rates should not exceed the predeveloped peak discharge rates for 2-, 10-, and 50-year return periods.~~ In general, matching discharge durations between 50% of the 2-year and 50-year will result in matching the peak discharge rates in this range.

The WWHM uses the predevelopment peak flow value for each water year to compute the predevelopment 2- through 100-year flow frequency values. The postdevelopment runoff 2- through 100-year flow frequency values are computed from the outlet of the proposed stormwater facility. The user must enter the stage-surface area-storage-discharge table (HSPF FTABLE) for the stormwater facility. The model then routes the postdevelopment runoff through the stormwater facility. As with the predevelopment peak flow values, the maximum

developed flow value for each water year will be selected by the model to compute the developed 2- through 100-year flow frequency.

The actual flow frequency calculations are made using the federal standard Log Pearson Type III distribution described in Bulletin 17B (United States Water Resources Council, 1981). This standard flow frequency distribution is provided in U.S. Geological Survey program J407, version 3.9A-P, revised 8/9/89. The Bulletin 17B algorithms in program J407 are included in the WWHM calculations.

~~The WWHM compares the postdevelopment 2-year flow frequency value with the predevelopment flood value. If the postdevelopment value is greater than the predevelopment value then flow frequency requirement has not been met. The same test is conducted for the 5-, 10-, 25-, 50-, and 100-year flow frequency values. The results are reported in the WWHM output.~~

~~The second half of the~~ Minimum Requirement #7 is based on flow duration. The WWHM will use the entire predevelopment and postdevelopment runoff record to compute flow duration. The standard requires that postdevelopment runoff flows must not exceed the flow duration values of the predevelopment runoff between the predevelopment flow values of 50 percent of the 2-year flow and 100 percent of the 50-year flow.

Flow duration is computed by counting the number of flow values that exceed a specified flow level. The specified flow levels used by WWHM in the flow duration analysis are listed below.

1. 50% of the 2-year predevelopment peak flow.
2. 100% of the 2-year predevelopment peak flow.
3. 100% of the 50-year predevelopment peak flow.

In addition, flow durations are computed for 97 other incremental flow values between 50 percent of the 2-year predevelopment peak flow and 100 percent of the 50-year predevelopment peak flow.

There are three criteria by which flow duration values are compared:

1. If the postdevelopment flow duration values exceed any of the predevelopment flow levels between 50% and 100% of the 2-year predevelopment peak flow values (100 Percent Threshold) then the flow duration requirement has not been met.
2. If the postdevelopment flow duration values exceed any of the predevelopment flow levels between 100% of the 2-year and 100% of the 50-year predevelopment peak flow values more than 10 percent of the time (110 Percent Threshold) then the flow duration requirement has not been met.
3. If more than 50 percent of the flow duration levels exceed the 100 percent threshold then the flow duration requirement has not been met.

The results are provided in the WWHM report.

Minimum Requirement #8 specifies that discharges to wetlands must maintain the hydrologic conditions, hydrophytic vegetation, and substrate characteristics necessary to support existing and designated beneficial uses. Criteria for determining maximum allowed exceedences in alterations to wetland hydroperiods are provided in guidelines cited in Guide Sheet 2B of the Puget Sound Wetland Guidelines (Azous and Horner, 1997).


Because wetland hydroperiod computations are relatively complex and are site specific, they ~~will have~~ not ~~yet been~~ included in the WWHM2. HSPF is required for wetland hydroperiod analysis. Ecology intends to include the ability to perform hydroperiod computations in WWHM3. ~~determine the appropriate steps in using HSPF to compute hydroperiod based on joint recommendations from wetland biologists and HSPF modelers.~~

WWHM Computation Steps: Ffor sizing a detention pond. Follow steps under Quick Start in WWHM2 under Help/Contents. These are also reproduced below:

Quick Start


Here is a brief set of steps to demonstrate pond sizing using the WWHM2.

1. On the map screen (the first screen that shows up) click somewhere within the county boundaries.



Tool bar

2. On the Tool bar (above the map screen) click the second button to switch to the Scenario Editor.



Schematic

3. Drag and drop the Basin Icon somewhere towards the top of the Schematic. You should then have a basin in your schematic flowing to the Point of Compliance (POC) The POC represents outflow or the sum of all flow from your project.

4. Left click on the basin you just added. This will open a window on the right where you can enter land use for this basin.

Land Use/ Vegetative Cover	Soil Type		
	A/B Outwash	C/D Till	Saturated
Impervious Area (Roof)	0	0	0
Streets/Sidewalks/Parking	0	0	0
Landscaped Area	0	0	0
Forest	0	0	0
Pasture	0	0	0
Pond	0	0	0

Standard Residential Land Use

Credits

2

UPDATE

Basin Information

5. Enter 10 acres in the field for Till Forest, and then click the Update button. You have now set your pre-developed conditions to 10 acres of Till Forest.



Change Scenarios

6. Now press the **Developed Unmitigated** button just below the schematic. Now you can enter basins and land use for your **Developed unmitigated Scenario**.

Now drag and drop a basin as you did in step 3. Click on it to enter land use as in step 4. This time instead of 10 acres of till forest, enter:

5 acres of Streets/Sidewalks/Parking.

3 acres of Landscaped Area.

1 acre of Impervious Area (Roof).

1 acre of Pond.

Be sure it's all in the middle column indicating it's on till soils as in the pre-developed Scenario. The screen should look like this:


Land Use/ Vegetative Cover	Soil Type		
	A/B Outwash	C/D Till	Saturated
Impervious Area (Roof)	0	1	0
Streets/Sidewalks/Parking	0	5	0
Landscaped Area	0	3	0
Forest	0	0	0
Pasture	0	0	0
Pond	0	1	0
Standard Residential Land Use			▼ ▲
Credits			▼ ▲

Developed Land Use

Then click the update button.

7. Now click the Developed Mitigated button below the schematic. This brings you to the final Scenario where your detention facility will be placed. Notice that your Developed basin is already there. Now drag and drop a pond into the space just below the basin. The schematic should look like this:

8.



Drag and drop a pond

8. Click on the pond to open the pond-editing window. You can edit any aspect of the pond from here, but for now, just click the Auto Pond button at the bottom. This will open up the **Pond Wizard** window.


The 'Pond Wizard' dialog box is shown. It has a title bar 'Pond Wizard' and a close button. Below the title bar is a section 'Automatic Pond Adjuster' with a progress bar. Under the progress bar are three radio buttons: '0-1 min Fast', '<---2-10 min--->', and '10 min+ Thorough'. Below these are input fields for 'Pond Depth (incl. 1 ft freeboard)' set to '7 ft.', 'Pond length to width ratio' set to '1 to 1', and 'Pond Side Slopes' set to '3 to 1'. Below these are 'Bottom Length' and 'Bottom Width' both set to '96.04 ft', and 'Volume at riser head' set to '1.806 acre ft'. Below this is a 'Choose Outlet Structure' section with a dropdown menu showing 'Choose Outlet Structure'. Below the dropdown is a 'Progress:' section with a green progress bar. At the bottom are four buttons: 'Create Pond', 'Optimize Pond', 'Accept pond', and 'Close'.

Pond Wizard

First choose an outlet structure from the drop-down list in the middle of the Pond Wizard form. Select the first option (1 Orifice & Rectangular Notch).

Next, press the Create Pond button. You will see a progress bar pop up to indicate that HSPF is running the model and the pond wizard is creating a pond according to the results.

9. The Pond Wizard will then automatically bring you to the **Run Model** screen.



Run Model Screen

You can view the results in graphs or tables. For yearly peaks, select a scenario to view (upper left) and click the yearly peaks button. Flow frequency and durations always show pre-developed vs. developed mitigated.

If you wish to change the pond and re-run the model, take the following steps:

- Go back to the Scenario editor (2nd Tool bar button).
- Chose the Developed Mitigated Scenario.
- Click on your pond.
- Change one or more pond values and click Update.
- Go back to the Run Model screen (3rd Tool bar button).
- Chose the developed mitigated Scenario.
- Check the Run HSPF and Duration Analysis check boxes.
- Click Run Analysis.

STEP 1. Location project site.
Drag flag to project site on map.
Zoom in or out on map, as needed.

Click on NEXT.

STEP 2. Input land area data.

Type in Name of Development, Development Address, City/County, and Project Description.

Select Standard Residential or Non-standard/Commercial.

For Standard Residential:

For Design Basin (project site) input number of acres of

Predeveloped Soils

Outwash (A&B)

Till (C)

Saturated (D)

Select Predeveloped Vegetation (Forest or Pasture)

Residential Acres

—— Lot Acres (excluding public right-of-ways and non-residential parcels)

Streets/Sidewalks (public right-of-ways)

Forest (undeveloped parcels only)

Pasture (undeveloped parcels only)

Landscaped Area (parks, etc., excluding residential lots)

Each of the above must be separated into A/B soils and C soils.

(NOTE: Saturated (D) soil areas should not be included in the developed area acres as these are wetland areas.)

Number of Lots (corresponding to the total Lot Acres)

(NOTE: the user is allowed a maximum of 10 lots per acre.)

Roof Runoff Credits (if appropriate)

Infiltrate (percent of lots)

Disperse (percent of lots)

Pavement Credit (if appropriate)

—— Porous Pavement (private pavement areas only)

Repeat information (if necessary) for Bypass.

Repeat information (if necessary) for Offsite Inflow.

Click NEXT.

Compute Runoff now? Click Yes.

For Non-standard/Commercial:

For Design Basin (project site) input number of acres of

Predeveloped Soils

Outwash (A&B)

Till (C)

Saturated (D)

Select Predeveloped Vegetation (Forest or Pasture)

Non-standard Residential/Commercial

Impervious Area (Roof acres)

Landscaped Area (pervious acres)

Streets/Sidewalks/Parking

Forest (undeveloped parcels only)

Pasture (undeveloped parcels only)

Each of the above must be separated into A/B soils and C soils.

~~(NOTE: Saturated (D) soil areas should not be included in the developed area acres as these are wetland areas.)~~

~~Pavement Credit (if appropriate)~~

~~——— Porous Pavement (percent of total Streets/Sidewalks/Parking)~~

~~Repeat information (if necessary) for Bypass.~~

~~Repeat information (if necessary) for Offsite Inflow.~~

~~Click NEXT.~~

~~Compute Runoff now? Click Yes.~~

~~STEP 3. Compute runoff.~~

~~HSPF executes for predevelopment and postdevelopment conditions.~~

~~Click NEXT.~~

~~STEP 4. Perform flow frequency analysis.~~

~~Click PERFORM to compute flow frequency values for predevelopment (black), flow duration values for predevelopment (red), and flow frequency values for postdevelopment without stormwater detention facility (blue).~~

~~2-Year to 100-Year flow frequency results are reported for the predevelopment and postdevelopment without detention facility conditions. If the difference in the 100-year flow frequency values is less than 0.1 cfs then no facility is required.~~

~~If needed to size a stormwater facility, click EXPORT to export either predevelopment, postdevelopment (without routing through stormwater facility), or postdevelopment (with routing through stormwater facility) runoff time series to a separate file.~~

~~Click NEXT.~~

~~STEP 5. Check stormwater detention facility.~~

~~Enter Facility Name/ID and Type of Facility.~~

~~Add Table from File or enter manually the following information:~~

~~Stage/depth (feet) starting zero~~

~~Area (acres) of surface corresponding to stage, starting at zero~~

~~Storage (acre-feet) of facility corresponding to stage, starting at zero~~

~~Discharge1 (cfs) from facility to surface flow, corresponding to stage, starting at zero~~

~~If the stormwater facility is an infiltration facility then click on Infiltration and enter:~~

~~——— Discharge2 (cfs) from facility to subsurface flow, corresponding to stage, starting at zero~~

NOTE:

- (1)the first row of values must be zero;
- (2)stage must increase from one row to next;
- (3)storage must increase from one row to next;
- (4)maximum number of total values cannot exceed 500.

Click NEXT.

Compute Runoff now? Click Yes.

Postdevelopment runoff is routed through the stormwater facility.

Click NEXT.

STEP 6. Perform flow frequency analysis for postdevelopment runoff with stormwater detention facility.

Click NEXT.

STEP 7. Compare flow duration statistics for predevelopment and postdevelopment runoff with stormwater detention facility.

Click lower PERFORM to compute flow frequency values for postdevelopment with stormwater detention facility (black) and flow duration values for postdevelopment with facility (red).

2 Year to 100 Year flow frequency results are reported for the postdevelopment with detention facility. Compare with predevelopment conditions.

Change 110 Percent Threshold (default value) if required by Ecology or local jurisdiction, otherwise use default value.

Click Perform Statistical Analysis to compare predevelopment and postdevelopment flow duration values.

Identify which values passed or failed the test.

Click NEXT.

STEP 8. Ecology Flow Control Standard Summary.

Summary information shows whether the stormwater facility passes or fails the Ecology flow control standard.

To view a complete listing of the input and output information:

- (1)save the file (File, Save Project As, enter File name, Save)
- (2)click Generate Report
- (3)view and/or print Report

To exit the WWHM: File, Exit

References for Western Washington Hydrology Model

Beyerlein, D.C. 1996. Effective Impervious Area: The Real Enemy. Presented at the Impervious Surface Reduction Research Symposium, The Evergreen State College. Olympia, WA.

Bicknell, B.R., J.C. Imhoff, J.L. Kittle Jr, A.S. Donigian Jr, and R.C. Johanson. 1997. Hydrological Simulation Program – Fortran User's Manual for Version 11. EPA/600/R-97/080. National Exposure Research Laboratory. Office of Research and Development. U.S. Environmental Protection Agency. Research Triangle Park, NC.

Dinicola, R.S. 1990. Characterization and Simulation of Rainfall-Runoff Relations for Headwater Basins in Western King and Snohomish Counties, Washington. Water-Resources Investigations Report 89-4052. U.S. Geological Survey. Tacoma, WA.

King County. 1998. Surface Water Design Manual. Department of Natural Resources. Seattle, WA.

United States Water Resources Council. 1981. Guidelines for Determining Flood Flow Frequency. Bulletin #17B of the Hydrology Committee. Washington, DC.